

## RE-PROGRAMMING YOUR REPAIRED

# RF1060 & 3M C1060

## HEADSET



## HEADSET:

- 1 Insert fully charged battery into headset.
- 2 Rotate mic towards the headband until it stops at the tab. *(See photo to the right).*
- 3 Insert base of headset into the programming station.
- 4 Press and hold the power button until the light flashes green.
- 5 Release the power button; your headset is now programmed.



## ENABLE TALK-LOCK:

- 1 Make sure headset is powered off.
- 2 Press and hold the **LOCK** button (center).
- 3 Press and release the power button while still holding the **LOCK** button until you hear audible tones. Power light will flash green, then change to red.
- 4 To engage talk-lock press the **LOCK** button again. A **RED LIGHT** means talk-lock is enabled.

Still having issues? Please call RF Drive-Thru at **(888) 966-6337** for customer support.