


RE-PROGRAMMING YOUR REPAIRED

PANASONIC ATTUNE II 450 HEADSET OR 420 BELT PACK




BASE STATION:

- 1 Touch the  **WRENCH** icon.
- 2 Enter password **12345**. (To change letters to numbers, press **aAI!** button twice).
- 3 Press **LOGIN**.
- 4 Press **HEADSETS**.
- 5 Press **ID REGISTRATION**. Press **START**, then press **YES**.

HEADSET:

- 6 Insert a charged battery. Keep powered off.
- 7 Press and hold **T1**, **T2**, and the **power** button. (Amber power light should blink.)
- 8 Press and release **T1**. Power and mic lights will turn solid amber. (May take several seconds.)

BASE STATION:

- 9 Press **STOP** on the base station. (Power light on the headset will turn solid green.)
- 10 Press the  **INFO** button to return to **MAIN MENU**.

Still having issues? Please call RF Drive-Thru at **(888) 966-6337** for customer support.