


APEX™ Drive-Thru Headset

Switches

- P** = Internal communication with other headsets
- V** = Headset volume control (toggle to cycle volume low to high, back to low)
- L1** = Communicate with Lane 1 when using dual lane
- L2** = Communicate with Lane 2



Light on Microphone Boom

- Solid green light** = Standby mode no car present in Lane 1
- Blinking green light** = Communicating with customer or internally
- Solid yellow light** = Standby mode no car present in Lane 2
- Blinking yellow light** = Communicating with Lane 2
- Blinking red light** = Headset not registered
- Blinking yellow/green** = Headset in registration mode

Replacing the Battery

- Press the red battery latch down (towards the ear pad) and the battery will eject
- Headset will turn off automatically after 10 minutes of no movement
- Pull battery using pull tab only



6-Port Battery Charger

LED Indicator


- See the status of the battery charge or if the battery is faulty




- Green light** = Battery is charged
- Yellow light** = Battery is charging
- Flashing yellow light** = Faulty battery

Follow these two steps to access the help menu to do any of the following tasks:

- **Register Headsets** (up to 32 headsets)
- **Program Alerts** (5 options)
- **Program Reminders** (30 options)
- **Program Greeters** (15 options)
- **Set Volumes**
- **Select a Lane Type**
- **Other Help Options**



Press the **Gear icon** on the bottom right hand side of the screen



Then you can access the **Help icon**